



DESIGNED TO MOVE [YOU][®]

JWM10A

QUICK REFERENCE GUIDE

Basic Operation

POWER/MODE: Push to turn on. Press to cycle through sources. Press & hold to turn OFF and enter standby mode.

AUDIO/SETTINGS: Press to bring up AUDIO ADJUSTMENT options: BASS, TREBLE, & BALANCE (left to right). Press & hold to bring up SETTING MENU options: BLUETOOTH (ON/OFF), BEEP, ADJUST LCD BRIGHTNESS, PRESET VOLUME and RESET. Press VOLUME UP/DOWN buttons will adjust each SETTING option except 'RESET'.

AUX IN: Insert 3.5mm cable from your portable media device.



VOLUME: Press the VOLUME UP ▲ (M) button to increase volume or Press the VOLUME DOWN ▼ (H) button to decrease volume.

ZONES OUTPUT: Press any zone button (ZONE A and ZONE B) to control corresponding speaker output from the radio, SPK A, SPK B will appear on the display.

RESET: Use a ball point pen or thin metal object to press the reset buttons.

BACK: Press to exit any menu.

App Control



App download and operation:

jControl app controls all of the primary functions of the JWM10A directly from your phone or tablet. It can be found by searching for "JENSEN jControl".

After downloading and installing app, pair your device to the JWM10A as instructed in "Bluetooth Operation" section in this guide. Once your device is paired, open the app and use as instructed. (Device must be paired to JWM10A before opening and using app).

Tablet Interface



Mode Menu

Zone Volume and Settings

Power

App Info

Back

Play/Pause/Mute

Forward

Volume Control

AM/FM Tuner Controls

VOLUME: Press the VOLUME UP ▲ (M) button to increase volume or Press the VOLUME DOWN ▼ (H) button to decrease volume.

MODE: Press repeatedly until you reach TUNER mode displayed as a frequency.

AS/PS: Press to SCAN through currently stored presets. Press & hold to STORE strongest broadcast stations in your area.



MUTE: Press to MUTE volume. Press again to resume volume.

TUNE/SEEK/TRACK: Press >|< button to tune frequency higher. Press <|> button to tune frequency lower. Press and hold to scan to next strongest station.

BAND: Press to select between two AM BANDS (AM1, AM2) & three FM BANDS (FM1, FM2, FM3).

STATION STORE PRESETS: Press & hold to store current station. Press once to recall stored channel.
NOTE: Up to 18 FM & 12 AM channels can be stored.

MODE: Press repeatedly until you reach BLUETOOTH mode.

SETTINGS: Press & hold to navigate through menu options, until BT menu options is reached. Press ENTER to select DEVICE LIST or PAIR.

ANSWERING PHONE: BT audio will automatically pause when a call is answered. It will then resume once call has ended. In some cases, it may be necessary to press the play button to resume the BT audio.



TUNE/SEEK/TRACK: Advance or reverse tracks on your device.

PAIR DEVICE VIA BLUETOOTH: (Make sure the device you intend to pair with is on and Bluetooth is enabled.) While in Bluetooth mode, press & hold PAIR to start the process. The JWM10A will then display 'PAIR' and be able to be paired with for 120 seconds. With your device in Bluetooth settings, 'JWM10A' should appear as an available device. Tap 'JWM10A' to connect. Enter the pairing (0000), if requested.

ALARM ON/OFF: Press & hold AUDIO/SETTING button to navigate through menu options, until Alarm ON/OFF menu option is reached. Press VOLUME UP/DOWN to turn ALARM ON or OFF.

ALARM SET: Press & hold AUDIO/SETTING button to navigate through menu options, until ALARM SET mode is reached. In Sleep mode menu, Press the VOLUME UP/DOWN to set Sleep timer: 15, 30, 45, 60, 0 minutes.



TIME SET: Press VOLUME DOWN (H) to adjust Hours and VOLUME UP (M) to adjust minutes when setting either CLOCK or ALARM time.

VIEW/SET: Press to access CLOCK VIEW mode. Press & hold to set CLOCK time.

For owner's manual, please visit <http://www.asaelectronics.com/manuals-guides>.