



DESIGNED TO MOVE [YOU]®

JWM40

QUICK REFERENCE GUIDE

Basic Operation

SPEAKER OUTPUT: Press either speaker zone button (A or B) to control corresponding speaker output from stereo. An A or B will appear on display when that zone is active.

POWER: Press to turn ON or OFF.

VOLUME: Rotate clockwise to increase volume or counter-clockwise to decrease volume.

AUDIO MENU: Press repeatedly to step through following audio adjustment options: BAS (Bass), TRE (Treble), and BAL (Balance). Rotate VOLUME encoder knob to adjust selected audio feature.

SYSTEM MENU: Press to enter system menu.

VIEW: Press to alternate between playing time and clock when in Tuner, Disc, USB or AUX modes.

BACK: While in a system menu, press to exit menu.



MODE: Press to access that particular mode.

AUX IN: Connect portable media player with standard 3.5mm (headphone) jack. (Must be in AUX mode to play device. Supports audio and video files.)

LCD BRIGHTNESS: Press ▲ to increase brightness. Press ▼ to decrease brightness.

AM/FM Tuner

AUTOMATIC STATION STORE: Select a band. Press and hold at least 3 seconds to scan for and store strongest stations for all bands.

PRESET SCAN: Select a band. Press to scan stations stored in that band. Unit will pause for 10 seconds at each preset station. Press again when desired station is reached.

TUNE/SEEK/TRACK: Press >> to tune frequency higher. Press << to tune frequency lower. Press and hold to scan to next strongest station.



MODE/BAND: Press to access TUNER mode and that particular band. Press AM button repeatedly to select band AM1 or AM2. Press FM button repeatedly to select band FM1, FM2 or FM3.

MANUAL STATION STORE/RECALL: Press and hold to store current station being played. Press once to recall stored station.
NOTE: 18 FM and 12 AM stations can be stored.

CD/DVD Player

PLAY/PAUSE: Press to suspend or resume disc play.

MENU: While in DVD mode, press to go to the DVD title menu.

TUNE/SEEK/TRACK: Press >> to advance to NEXT TRACK (CD) or CHAPTER/TITLE (DVD). Press << to go back to PREVIOUS TRACK or CHAPTER/TITLE. Press and hold >> to FAST FORWARD or << to REVERSE/REWIND. Press >| to resume playback.



EJECT: Press to EJECT disc.

MODE: Press to access DISC mode.

1: Press once to suspend disc play, and twice to STOP disc play.

3: Press to SHUFFLE songs. Press again for SEQUENTIAL play.

4: When playing CD, press repeatedly to step through REPEAT play options: RPT ONE, RPT ALL, RPT OFF. When playing DVD, press repeatedly to step through repeat play options: RPT Chapter, RPT Title, RPT All, RPT OFF.

5: Press to go to previous folder.

6: Press to go to next folder.

ENTER: Press to select menu item (DVD).

MP3/USB Playback

PLAY/PAUSE: Press to PLAY or PAUSE current audio or video.

TRACK SELECT: Press << to go back to PREVIOUS TRACK and >> to advance to NEXT TRACK. Press and hold >> to FAST FORWARD and << to REVERSE. Press >| to resume playback.



MODE: Press to access USB mode.

USB INPUT: Connects a USB flash/thumb drive for audio playback and/or charging.

3: Press to SHUFFLE tracks. Press again for SEQUENTIAL play.

4: Press repeatedly to step through REPEAT play options: RPT 1 (track), RPT DIR (folder), RPT ALL (disc), RPT OFF.

5: Press to access a higher folder level.

6: Press to access a lower folder level.

ENTER: Press to confirm menu selection.

Bluetooth

TRACK: Press to go to your device's PREVIOUS or NEXT TRACK.



MODE: Press to access Bluetooth mode.

PAIR DEVICE: (The device you intend to pair with must be on and have Bluetooth turned on.) Press and hold to make available to pair for 120 seconds. On your device, enter Bluetooth section within Settings. *JWM40* will appear in a list of available devices. Select to pair and connect. Enter "0000" if prompted for a password.

SETTINGS: While in Bluetooth mode, press repeatedly to step through settings options:

BT DEV: Press ENTER to access Device List.

BT PAIR: Press ENTER to make available to pair for 120 seconds.

BT ON/OFF: Rotate encoder knob to turn BT ON or OFF.

Clock with Alarm

VIEW: Press to alternate between playing time and clock when in Tuner, Disc, USB or AUX modes.

ALARM ON/OFF: Press to turn ON or OFF.

ALARM SET: Press and hold until alarm time begins to blink. Press HOUR button repeatedly to adjust hour, and MINUTE button repeatedly to adjust minute. Then press ALARM button again to save.



SLEEP TIME SET: Press to access. Press repeatedly to step through SLEEP TIMES of 0, 15, 30, 45, 60 minutes.

CLOCK SETUP: With CLOCK displayed, press and hold either button until time begins to blink. Press HOUR button repeatedly to adjust hour, and MINUTE button repeatedly to adjust minute. Setup mode will time out after 10 seconds if nothing else is done and time will be saved.

For owner's manual, please visit www.asaelectronics.com/manuals-guides.