



MSR4115 Troubleshooting Guide

Radio will not turn ON

- Try the RESET button.
- Check fuse.
- Confirm 12V+ on the ACC+ wire (RED wire).
- Confirm 12V+ on the Memory/Battery (YELLOW wire).
- Confirm Ground.

Radio turns ON, but no sound

- Verify **Volume**, **Fader/Balance**, **Mute** controls are set correctly (see owners manual).
- Try RESET button.
- Verify proper speaker connections.
- Check for shorts or loose connections on speaker wires.

CD does not load fully

- Make sure unit has power and no other CD is currently inside.
- Inspect radio's chassis to verify shipping screw(s) have been removed.

CD does not play correctly

- Check to make sure CD is inserted correctly.
- Verify CD is free from dirt, scratches, etc.
- Check with factory CDs.
- Check factory original CDs for compatibility warnings (due to various copy-protection, multi-media content, etc).
- Disc skips during playback – verify you have not exceeded 30 degrees mounting angle.

No AM or FM reception

- Verify you are tuned to a valid station.
- Check your antenna connection on rear of stereo.
- Try a different antenna.

No Satellite Radio reception

- See Owners' Manual for correct operating instructions.
- Verify you have the optional equipment installed (satellite radio tuner & satellite radio antenna).
- Verify the antenna has a clear view of the sky and there are no line-of-sight blockages of the signal to the antenna (roof air conditioners, TV antennas, etc).
- Verify you have activated the subscription service with Sirius.
- Verify with preview channel (184).

No Audio from Left or Right Side while in Sirius mode

- If no Audio is present on one side or the other (Left or Right) while listening to Sirius, inspect data cable for missing or bent pin on either end. Data cable should have eight pins on both ends.