

Date: 9/18/2023  
Doc. Revision: A  
Revision Date:  
ASA Model #: JHD62B

# Work Instruction: JHD62B

Written By  
R. Priddy  
Approved By  
Joe Caban

1. Pull parts per JDE work order.
2. Place the harness in the original box.
3. Place 2x4 Part number/bar code label on the outside of the box.
4. Get first article inspection.

