Date:	10/30/2023	144 1 1 4 4 11 11 11 11 11 11 11 11 11 1		Written By
Doc. Revision:	А			R. Priddy
Revision Date:				Approved By
ASA Model #:	JHD62PED			Joe Caban

- 1. Pull parts per JDE work order
- 2. Place parts in the box
- 3. Put label on the outside of the box.
- 4. Get First article inspection.



10/30/2023