Date:	10/16/2023			Written By
Doc. Revision:	А	Work Instruction: JTV2423DCSJ		R. Priddy
Revision Date:				Approved By
ASA Model #:	JTV2423DCSJ			Joe Caban
1. Pull parts per JDE	work order			
2. Open box, leave T	TV in the box. Cut a small	opening in the plastic bag to access the 2 taps on the top of the TV		~
3. Use pry tool to pry the edge of the tv apart. Do not insert pry tool more than an 1/8 of an inch into the grove.				TOS MINOS.HO
4. Place a small amount of glue on the tabs and snap back together. Clean up any glue residue.				
5. Tape bag back together.			F = 1	
6. Add 4- 2x4 barcode/partnumber label to coverup each label on All 4 sides. Add yellow dot.				
7. Get first article ins	spection.			

10/16/2023