Date:	10/18/2022		Written By
oc. Revision:	D	Work Instruction: VAVS360FRP	R. Priddy
Revision Date:			Approved By
SA Model #:	VAVS360FRP		Joe Caban

- 1. Pull parts per JDE work order
- 2. Place parts in the box
- 3. Put label on the outside of the box.
- 4. Get First article inspection.





10/18/2022