

Date: 8/17/2023  
Doc. Revision: A  
Revision Date:  
ASA Model #: VOS7M140IWP

# Work Instruction: VOS7M140IWP

Written By  
R. Priddy  
Approved By  
Joe Caban

1. Pull parts per JDE work order
2. Place parts in the box
3. Put label on the outside of the box.
4. Add packing bubbles and trim box down if necessary

