Date:	1/4/2021
Doc. Revision:	Α
Revision Date:	

Work Instruction: ZAEJHD1630SXM

Written By R. Priddy

Approved By Joe Caban

ASA Model #: ZAEJHD1630SXM

- 1. Pull parts per JDE work order
- 2. Place all parts in box.
- 3. Label master carton with part number/barcode and with quantity.
- 5. Get first article inspection.





1/4/2022