Date:	10/18/2023		Written By	
Doc. Revision:	А	Work Instruction: ZAEJHD22HD		R. Priddy
Revision Date:				Approved By
ASA Model #:	ZAEJHD22HD			Joe Caban

- 1. Pull parts per JDE work order
- 2. Place parts in the box
- 3. Put label on the outside of the box.
- 4. Get First article inspection.





10/18/2023