

Date: 10/26/2020
Doc. Revision: A
Revision Date:
ASA Model #: 63168450

Work Instruction: 63168450

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE Work order
2. Add all parts to the box
3. Place 2x4 part number/bar code label on the side of the box.
4. Get first article inspection.

