

Date: 5/10/2022
Doc. Revision: A
Revision Date:
ASA Model #: 63571150

Work Instruction: 63571150

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order
2. Place parts in the box
3. Put label on the outside of the box.
4. Get First article inspection.

