

Date:	1/7/2022	Work Instruction: 7261784	Written By
Doc. Revision:	A		R. Priddy
Revision Date:			Approved By
ASA Model #:	7261784		Joe Caban

1. Pull parts per JDE work order
2. Build retail box.
3. Place all parts in box with packing bubbles
4. Label master carton with part number/barcode and with quantity.
5. Get first article inspection.

