

Date: 2/2/2021  
Doc. Revision: A  
Revision Date:  
ASA Model #: 7362518

# Work Instruction: 7362518

Written By  
R. Priddy  
Approved By  
Joe Caban

1. Pull parts per JDE work order
2. Add all parts to box.
3. Place part number/barcode 2x4 label on the outside of the plastic bag.
4. Get First Article Inspection.

