

Date:	1/14/2020
Doc. Revision:	A
Revision Date:	
ASA Model #:	7384579

Work Instruction: 7384579

Written By
R. Priddy

Approved By
Joe Caban

1. Pull parts per JDE work order
2. Build and add part number label (As seen in *Photo: 1*)
3. Place all parts into the box and add packaging bubbles.
4. Get first article inspection.

Photo: 1



Photo: 2

