

Date:	1/4/2021	Work Instruction: 93615125	Written By
Doc. Revision:	A		R. Priddy
Revision Date:			Approved By
ASA Model #:	93615125		Joe Caban

1. Pull parts per JDE work order
2. Place all parts in box.
3. Label master carton with part number/barcode and with quantity.
5. Get first article inspection.

