

Date: 2/16/2021
Doc. Revision: A
Revision Date:
ASA Model #: ADVUNI400CPRTL

Work Instruction: ADVUNI400CPRTL

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order
2. Place 4 pcs 34201001 black screws in a bag.
3. Remove transporter screws and the plastic protective cover.
4. Attach side brackets with 34201000 phillips flat head screw.
5. Add radio cage and trim ring.
6. Add harness and bag with the 4 screws and all parts to original box.
7. Add 2x4 part number label over original part number.
8. Get First Article inspection.

