

Date: 4/10/2023  
Doc. Revision:  
Revision Date:  
ASA Model #: BCTJHD1635BT

# Work Instruction: BCTJHD1635BT

Written By  
R. Priddy  
Approved By  
Joe Caban

1. Pull parts per JDE work order
2. Add harness to the original box.
3. Put label on the outside of the box.
4. Get First article inspection.

