

Date: 12/4/2023
Doc. Revision: A
Revision Date:
ASA Model #: BCTJHD62

Work Instruction: BCTJHD62

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order
2. Place parts in the box
3. Put label on the outside of the box.
4. Get First article inspection.

