

Date: 11/14/2022
Doc. Revision: A
Revision Date:
ASA Model #: CVPS192FLEXT

Work Instruction: CVPS192FLEXT

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order.
2. Pull the sensor ext out of the box from the CVPS192EXT.
3. Add the sensor CVPS192EXT into the box with the CVPS192FL.
4. Place the label over the original part number.
5. Get a first article inspection.

