

Date: 3/2/2022
Doc. Revision: A
Revision Date:
ASA Model #: JHD1130FRD

Work Instruction: JHD1130FRD

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order
2. Place harness in the box.
3. Place part number label on the outside of retail box.
4. Label outside of the master carton.
5. Get first article inspection.

