

Date: 6/30/2023  
Doc. Revision: B  
Revision Date:  
ASA Model #: JHD12PED

# Work Instruction: JHD12PED

Written By  
R. Priddy  
Approved By  
Joe Caban

1. Pull parts per JDE work order
2. Pull the original harness (31100100) add part number label to the harness and put into stock.
3. Replace the original harness with the 31100105.
4. Add 2x4 part number/barcode label.
5. Get first article inspection.

