

Date: 10/4/2022
Doc. Revision: A
Revision Date:
ASA Model #: JHD1635BTFRD

Work Instruction: JHD1635BTFRD

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order.
2. Place harness in the original box
3. Place 2x4 part number label on the original box.
4. Place 2x4 Part number/bar code label on the outside of the box.
- 5.. Get first article inspection.

