

Date: 9/13/2023
Doc. Revision: A
Revision Date:
ASA Model #: JHD22K1

Work Instruction: JHD22K1

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order
2. Remove the original harness. Label with part number 31100100. Put into stock
3. Add the KUB1 harness.
4. Put a part number barcode label on the outside of the box and a label on the outside of the master box.
5. Get first article inspection.

