

Date: 8/29/2023
Doc. Revision: A
Revision Date:
ASA Model #: JHD62K1

Work Instruction: JHD62K1

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order
2. Remove the original harness
3. Add the KUB1 and JMICHFP to the foam packer
4. Place labels on the bottom of the original box.
5. Put the radio and harness back into the original package.
6. Put a label on the master carton.
7. Get a first article inspection.

