

Date: 11/19/2019  
Doc. Revision:  
Revision Date:  
ASA Model #: JMS3RTL

# Work Instruction: JMS3RTL

Written By  
R. PRIDDY  
Approved By  
J. CABAN

1. Pull parts to JDE Work Order.
2. Build retail box. (photo: 1)
3. Place JMS3 in retail box. (Photo: 2)
4. If master box is pulled. Place 2x4 part number/barcode label on outside of the box.
5. Have first article inspection done.

Photo: 1



Photo: 2

