

Date: 2/2/2023
Doc. Revision: A
Revision Date:
ASA Model #: KUBSVLCAMKIT

Work Instruction: KUBSVLCAMKIT

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order
2. Place parts in bag and seal. And then in box
3. Put label on the outside of the box.
4. Get First article inspection.

