

Date: 6/19/2023
Doc. Revision: A
Revision Date:
ASA Model #: MOOMBACAM1

Work Instruction: MOOMBACAM1

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order
2. Place parts and packing bubbles in the box
3. Put label on the outside of the box.
4. Get First article inspection.

