

Date: 11/14/2022
Doc. Revision: A
Revision Date:
ASA Model #: OB74MM150FL

Work Instruction: OB74MM150FL

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order.
2. Place all parts in box add bubble packing.
3. Place 2x4 Part number/bar code label on the outside of the box.
4. Get first article inspection.

