

Date: 4/26/2022
Doc. Revision: A
Revision Date:
ASA Model #: SWVCMS24JD3

Work Instruction: SWVCMS24JD3

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order
2. Put bracket and cable in the box with the camera.
3. Put cameras and bubbles into a kit box
4. Put part number and barcode label on the outside of the box.
5. Get first article inspection.

