

Date: 11/17/2015
 Doc. Revision: B
 Revision Date: 2/7/2020
 ASA Model #: SXV300V1M

Work Instruction: SXV300V1M

Written By
 B. Woods
 Approved By
 D. Stoltzfus

1. Pull items for kit as per Work Order/JDE
2. Remove antenna. Place 1x3" label with "R169159" model to bag (as shown).
3. Place a 2x4 Part number Label in the lower corner of the product box right do not cover serial number.
4. Place 1x2 label with UPC # 6 81787 02085 8 code over existing UPC.
5. Antenna will be brought into stock as R169159.
6. Get first piece inspection.

