

Date:	5/4/2021	Work Instruction: UM2DSPWH	Written By
Doc. Revision:	A		R. Priddy
Revision Date:			Approved By
ASA Model #:	UM2DSPWH		Joe Caban

1. Pull parts per JDE work order
2. Add harness to original box.
3. Place part number/barcode 2x4 label on the outside of the box.
4. Get First Article Inspection.