

Date: 10/28/2021
Doc. Revision: A
Revision Date:
ASA Model #: UMPA4WH

Work Instruction: UMPA4WH

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE Work order
2. Put harness in original box.
- 3.. Get first article inspection
4. Add 2x4 part number/barcode number

