

Date:	5/4/2021	Work Instruction: UMPA8WH	Written By
Doc. Revision:	A		R. Priddy
Revision Date:			Approved By
ASA Model #:	UMPA8WH		Joe Caban

1. Pull parts per JDE work order
2. Add Harness to original box.
3. Place part number/barcode 2x4 label on the outside of the plastic bag.
4. Get First Article Inspection.