

Date: 2/24/2022
Doc. Revision: A
Revision Date: 2/25/2022
ASA Model #: UMS88WH

Work Instruction: UMS88WH

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE Work order
2. Add harness to original box.
3. Place part number/barcode 2x4 label on the outside of the box
4. Get first article inspection.

