

Date: 2/18/2020
Doc. Revision: A
Revision Date:
ASA Model #: VOM719WPHD3B

Work Instructions: VOM719WPHD3B

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order
2. Build box and add part number/barcode label
3. Place all parts into the box and add packaging bubbles.
4. Get first article inspection.

Photo: 1



Photo: 2



Photo: 3

