

Date: 5/23/2022  
Doc. Revision: A  
Revision Date:  
ASA Model #: VOM73MMT172BKIT

# Work Instruction: VOM73MMT172BKIT

Written By  
R. Priddy  
Approved By  
Joe Caban

- 1. Pull parts per JDE work order
- 2. Place parts in the box
- 3. Put label on the outside of the box.
- 4. Get First article inspection.

