

Date: 7/23/2020
Doc. Revision: A
Revision Date:
ASA Model #: VOS719AS1

Work Instruction: VOS719AS1

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order
2. Build and add part number/barcode label to the box
3. Place all parts into the box.
4. Get first article inspection.

