

Date: 1/20/2021
Doc. Revision: A
Revision Date:
ASA Model #: VOS719WPLD1B

Work Instruction: VOS719WPLD1B

Written By
R. Priddy
Approved By
Joe Caban

1. Pull parts per JDE work order
2. ADD all parts to master box
3. Place part number/barcode 2x4 label on the box
4. Get First Article Inspection.