

Date: 12/8/2021  
Doc. Revision: A  
Revision Date:  
ASA Model #: WVSXP70

# Work Instruction: WVSXP70

Written By  
R. Priddy  
Approved By  
Joe Caban

1. Pull parts per JDE work order
2. Build retail box.
3. Place monitor and camera in the retail box.
4. Label master carton with part number/barcode and with quantity.
5. Get first article inspection.

