



Installation instructions for the JENSEN HD1BT Harley Davidson replacement stereo

1. Pull out the 40 Amp fuse in the fuse box, for the ignition before beginning the removal and installation
2. Unplug the clip on the bottom of the factory radio for the ignition wire harness before pulling the radio out DO NOT PULL ON THIS HARNESS, JUST UNCLIP IT FROM THE RADIO
3. Be very careful when pulling out the antenna from the factory radio as this may have corroded and become somewhat stuck. DO NOT PULL IT BY THE CABLE! Try to get a hold of the base of the plug possibly using pliers if necessary.
4. Unplug all plugs from the back of the factory radio
5. Remove the 4 bolts (2 on each side of the radio) and save them for the installation of the new radio
6. Pull the factory radio out toward the front of the bike, through the Fairing
7. Insert the new radio from the driver's side of the fairing, feeding the wires in thru the hole first until the mounting holes match up with the mounting holes on the bike
8. Insert the same mounting bolts you pulled out of the factory radio into the mounting holes in the new radio. This can be very tricky and may require another set of hands or a very long pair of needle nose pliers to hold the bolt while you get it started.
9. BE CAREFUL TO KEEP THE BOLTS LINED UP CORRECTLY SO NOT TO CROSS THREAD THE BOLTS INTO THE RADIO
10. If your factory radio harness has a Black and a Grey connector be sure to attach the Black Harness plug into the Black plug on the back of the new JENSEN Stereo
11. If you have factory rear speakers you will need to use the pigtail included with the radio to connect the rear speakers. Locate the proper 4 wires in the grey harness to connect to the pigtail for Left Rear plus & minus and Right Rear plus & minus
12. If you are adding rear speakers or a second set of speakers just connect the speaker wire for these two speakers to the pigtail included with the radio and then plug that into the corresponding waterproof connector coming off the back of the radio.
13. You will probably want to either run a USB extension cable to a windshield bag or install one of our JEN-AUX panel mount input panels. If you decide to mount this in the fairing carefully consider where you mount it so you will not dent your gas tank if you have a USB stick plugged into the input and turn the handlebars too far. This could also be run to the saddlebags or tour pack if available.
14. Tie up any and all loose wires with zip ties to clean up the installation and avoid pinching any wires in the fairing.