

Voyager[®]

Auto-Pairing

Our new auto-pairing system allows operators to switch from implement to implement without moving the cameras.



WVO57APCL1B
7" Auto-Pairing System Only



WVO55APCL1B
5.6" Auto-Pairing System Only

EXPAND your vision[™]

Voyager[®]

Auto-Pairing

These unique auto-pairing systems allow for operators to view one camera from two separate monitors.

How this works:

The splitter splits the signal, from any wired camera, in two directions:

1. to a wired monitor
2. to the wireless auto-pairing transmitter, that send the signal to the wireless auto-pairing monitor



WVO57APNC

7" Auto-Pairing System with 2 monitor viewing

- System includes splitter and two harness adaptors
- Requires 1-camera wired observation system (VOS7MDCL1B)



WVO55APNC

5.6" Auto-Pairing System with 2 monitor viewing

- System includes splitter and two harness adaptors
- Requires 1-camera wired observation system (VOS7MDCL1B)

EXPAND your vision[™]

Features and specifications subject to change without notice.