




PTR425

Clock Adjustment Instruction



1. When the unit displays the clock, press and hold the volume knob for 1.5 seconds. The clock's hour digit will blink.
2. Rotate the volume knob to adjust from 1-12. The AM/PM icon will change when passing over 12.
3. Push the volume knob once, the clock's minute digit will blink.
4. Rotate the volume knob to adjust from 00-59.
5. Press and hold the volume knob for 1.5 seconds to confirm the adjustment.