




JE2414






PANEL CONTROLS

ITEM	DESCRIPTION
A	SOURCE BUTTON
B	MENU BUTTON
C	CHANNEL UP
D	CHANNEL DOWN
E	VOLUME INCREASE
F	VOLUME DECREASE
G	POWER BUTTON

I/O DETAIL VIEW SHOWN FROM BACK VIEW

ITEM NO	DESCRIPTION	ITEM NO	DESCRIPTION
1	POWER CORD (72.00±1.00)	6	Y Pb Pr COMPONENT VIDEO
2	USB	7	RF IN
3	HDMI (ARC)	8	HEADPHONE
4	VGA	9	SPDIF
5	PC AUDIO	10	AUDIO/VIDEO
		11	AUDIO OUT

JE2415



PANEL CONTROLS

ITEM	DESCRIPTION
A	SOURCE BUTTON
B	MENU BUTTON
C	CHANNEL UP
D	CHANNEL DOWN
E	VOLUME INCREASE
F	VOLUME DECREASE
G	POWER BUTTON

I/O DETAIL VIEW SHOWN FROM BACK VIEW

ITEM NO	DESCRIPTION	ITEM NO	DESCRIPTION
1	POWER CORD (72.00±1.00)	6	HDMI (ARC)
2	HEADPHONE	7	RF IN
3	SPDIF	8	USB
4	Y Pb Pr COMPONENT VIDEO		AUDIO OUT
5	VGA / AUDIO		