



GMRS4WM Troubleshooting Guide

Indicator Lights

- **Green** – Fully charged, ready for use.
- **Red** – Power applied, charging.
- **Blinking Red** – Try re-seating handsets in charger.
- **Red briefly, then dark** – The batteries are most likely too depleted. Try recovering them through one or two charging cycles on a stand-alone battery charger. Re-test in GMRS4WM.
 - Replace batteries with new. See owner's manual for proper replacement batteries.
- **Dark** –
 - Verify 12V+ Power connection.
 - Verify Ground connection.
 - Check in-line fuse.