



MRF27 Troubleshooting Guide

Wired Remote Control not functioning

- Verify the Remote Receiver Module is properly connected to the designated “**Wired Remote**” pigtail and not inadvertently connected to the **Sirius Module** or **iPod** pigtails.
- Verify there are no bent pins in connectors.
- Remote not programmed to Receiver Module. Follow programming instructions in manual to reprogram remote.
- Replace battery (CR2032).

Poor reception

- The black wire is the antenna. Make sure this is not inadvertently Grounded.
- For best reception, do not coil antenna. Route antenna so that it can be fully extended. Try to avoid running parallel to power wires.

Note: RED wire is for programming use only. Do not connect this to 12V+ except during programming sequence.