



AVP9000 Troubleshooting Guide

Unit will not turn ON

- Check fuse.
- Check 12V+ on RED wire.
- Check Ground.

Unit turns ON, but no sound

- Verify sound system is ON and set properly (input & volume).
- Verify Audio cable is connected from AVP7000 to TV or sound system.

Video Cassette does not load fully

- Make sure unit has power and no other video cassette is currently inside.

Video Cassette plays sound but no video

- Make sure the video cable is routed from the video output to the input on the television.

Unit does not respond to Remote Control

- Verify that you have a clear line of sight for the IR signal.
- Check the batteries.
- Confirm the remote IR eye has a solid connection (if applicable).

Unit will not play; Dew light is ON.

- Unit will not play when in Dew mode.
- Take unit inside.
- Carefully blow warm air inside unit to dry Dew sensor.