



GMRS100/GMRS200 RADIO TROUBLESHOOTING GUIDE

No transmission while pressing the PTT button

- Verify batteries are properly charged.
- Verify proper polarity of batteries in radio.

Weak or no signal received

- Verify batteries are properly charged.
- Verify proper channel is set to target transceiver.
- Verify privacy code is not set the same as target transceiver.
- Verify volume is not set too low.
- Verify PTT button is not inadvertently depressed.
- Check for excessive radio interference on particular channel selected.
- Check for obstructions, possible signal block.

Unit beeps, but will not function when turned on

- Verify batteries are properly charged.

Reception of unwanted signals

- Check for, and remove if possible, interference from other electronic devices.