

TUNE/SEEK/TRACK:

Advance or reverse tracks on your device.

▶||: Press to PLAY or PAUSE current audio or video.

ANSWERING PHONE: BT audio will automatically pause when a call is answered. It will then resume once call has ended. In some cases, it may be necessary to press the play button to resume the BT audio.



PAIR DEVICE VIA BLUETOOTH: Make sure the device you intend to pair with is on and ready to pair.

1. Press PAIR button to enter Bluetooth mode.
2. Press & Hold PAIR button to start Bluetooth pairing process. The JWM72A will display "PAIRING" and will be available to pair for 120 seconds.
3. In your device Bluetooth settings, select "JWM72A" to connect.

MODE: Press repeatedly to cycle through available modes until Bluetooth is reached, and press ENTER KNOB to select.

SETTINGS: Press & Hold to bring up setting menu and press to navigate through menu options, until BT menu is reached Press ENTER to select DEVICE LIST or PAIR.

PLAYBACK MENU: Press to bring up PLAYBACK MENU options: RANDOM (on/off), REPEAT (one/dir/all/off), INTRO (on/off) and FOLDER/FILE select. Rotate VOLUME KNOB will adjust each playback menu option. Press **◀** or **▶** to navigate menu options.

BACK: Press to exit playback menu.

VOLUME: Rotate clockwise to increase volume or counter-clockwise to decrease corresponding zones volume.



TUNE/SEEK/TRACK: Press **▶** button to advance to NEXT TRACK. Press **◀** button to advance to PREVIOUS TRACK. Press & Hold additional times to step through x2, x4, x8, x20. Press PLAY (**▶||**) to resume.

MODE: Press repeatedly to cycle through available modes until USB is reached, and press ENTER KNOB to select.

PLAY/PAUSE: Press to PLAY or PAUSE current audio or video.

USB: Connect a USB flash/thumb drive for audio playback or mobile device for charging.

BACK: Press to exit time menu.

SLEEP TIMER /ALARM/CLOCK SET: Repeated presses will cycle through the TIME menu setting options: SLEEP timer (OFF, 15, 30, 45, 60 minutes), ALARM (on/off), ALARM SET, CLOCK SET. Rotate the VOLUME KNOB to adjust hour or minute when setting either CLOCK or ALARM time. Press ENTER KNOB to change to minute adjustment.



DIMMER: Press to switch the DIMMER (on/off). Press & Hold to bring up brightness setting. Rotate the VOLUME KNOB to adjust the brightness (Off, 1, 2, 3, 4, 5, 6, 7, 8).

For owner's manual, please visit <http://www.asaelectronics.com/manuals-guides>.