



## **VCMS12L&R Troubleshooting Guide**

### **No image on monitor**

- Verify camera cable connection at monitor.
- Verify camera is connected to camera cable.
- Connect camera directly to monitor if possible.
- Connect known good camera/cable to monitor.
- Connect known good camera to existing cable.
- Connect known good cable between monitor and existing camera.

### **Flickering or rolling Image**

- Switch to secondary camera input on monitor.
  - If image is stable, replace monitor.
- Check for 12V+ to monitor.
- Connect known good camera/cable to monitor.
  - If image is stable, check camera/cable.
  - If image still flickers/rolls replace monitor.

### **No color**

- Verify monitor supports color feature.
- Verify proper lighting.
- Connect known good camera.
- Check the condition of the cabling between camera and monitor.

### **Reverse Image**

- On some VOYAGER Monitor models there are provisions for reversing the image. Please refer to the monitor manual for location and instructions.